

Photo Manager for Photo Frame
(Auto Run PC software)

User manual

PHILIPS

Content

Philips. © 2006
2006.7 First Version V06.07.1

1.	Welcome to Auto Run PC Software	- 3 -
2.	What's New in Auto Run PC Software	- 3 -
3.	Getting Started	- 4 -
3.1.	System Requirement.....	- 4 -
3.2.	About the Auto Run PC Software User Interface.....	- 4 -
4.	The PC Area Pane	- 6 -
5.	The Photo Frame Area Pane.....	- 10 -
6.	The Command Keys Pane.....	- 12 -

1. Welcome to Auto Run PC Software

Philips Auto Run Program for Photo Frame is a windows based application for user to manage photos between Philips Photo Frame and PC. It provides easy-to-use user interface for user to browse and preview the photos in both PC directories and Photo Frame albums, and for user to perform operations, such as copying, moving and deleting photo(s).

2. What's New in Auto Run PC Software

This is the first version of the Philips Auto Run Program for Photo Frame.

- Sharing photos between PC and Philips Photo Frame.
- Automatically resizing the photos to match Photo Frame resolution.
- Copying the Photos between PC and Philips Photo Frame by using drag-and-drop functions.
- Retrieving removed photos from Auto Run Recycle Bin.
- Automatically detecting Philips Photo Frame.

3. Getting Started

3.1. System Requirement

- Computer Hardware Basic Requirements: Minimum: Pentium III 500MHz processor or equivalent or above, 128MB RAM, 100MB free HDD space, 16-bit High Color display adapter.
- Supported PC Operating System: MS Windows XP, and MS Windows 2000.
- Supported Languages: Chinese Simplified, Chinese Traditional, English, French, German, Italian, Japanese, and Spanish.

3.2. About the Auto Run PC Software User

Interface



After installing this Auto Run Program, this application will start automatically and reside at taskbar as tray icon when each time user login into his/her account. You may find this tray icon  in the Windows taskbar. You can bring up the Auto Run Program main window manually by right-clicking this tray icon and selecting “Show Photo Manager”. You may also terminate this application by selecting “Terminate Photo Manager” options.



Fig.1

Auto Run Program will show up its main window automatically while Philips Photo Frame connecting to your PC through USB cable. You may also double click double-click desktop shortcut  to bring up this application as shown below.




Fig.2

① The PC Area Pane

On the left side of Auto Run Program, the PC Area Pane displays the folder tree structures in the very same way as Windows File Manager, and also shows photos in the selected folder in thumbnail views. The thumbnail view in this area will display “No Photo” if there is no qualified photo for Philips Photo Frame, which can only display standard JPEG format files.

[CAUTION] Please be aware that even this view shows “No Photo”, this folder might contain other files, and might not be empty.

② The Photo Frame Area Pane

On the right side of Auto Run Program, the Photo Frame Area Pane displays Photos in albums or folders of the Photo Frame and its external memory cards. Its thumbnail view will show “Disconnected” message while Philips Photo Frame is not connected to your PC.

You may copy photos between PC and Photo Frame by drag-and-drop photos between “The PC Area Pane” and “The Photo Frame Area Pane”.

③ Command Keys Pane

Command Key Pane is just beneath PC/Photo Frame Panes, and contains the functional button for Photo Copy, Cut, Past and Delete operations. Within the Command Key Pane, you may click setup button to setup desired language, and use recycle bin button to bring back the deleted photos.

4. The PC Area Pane






Fig.3

- ① **Folder Tree View** : Display all folders and recycle bin in tree structures similar to Windows File Manager. If user clicks the desired folder, all photos in the folder will be shown in Photo Thumbnail View (2).
- ② **Photo Thumbnail View** : Display all photos in thumbnail view based on the user selected folder from folder tree view (1).
- ③ **Photo Preview Area** : Display the user selected picture with detail information, such as file name, file size and photo resolution.
- ④ **Slide Bar** : You may click  to move the Slide Bar left and increase the Photo



Fi

Auto Run Program can perform auto resizing for all photos copied to Photo Frame. You are also free to crop photos of more than 540x720 or 720x540 pixels, in Crop Photo window by double clicking the photos in thumbnail view as shown in Fig 5.




Fig.5

① **Preview of cropped photo**

In this preview area, Auto Run will show cropped photo results. (1)

② **Cropped Area**

Display the original photo in thumbnail view and cropping area in red rectangle, which presents the cropping area with 540x720 or 720x540 pixels. You may use a mouse to drag this rectangle area into your desired area.

③ **Photo Information**

Display all the information related to this current selected photo, including Album Name, Date Time, and Photo Description.

④ **Command Keys**

- Close Button: Close this window without performing any actions.
- Crop Photo: Perform the crop action, and save the cropped file in the same folder. The saved file will carry the same filename plus a number index. For example, if the original filename is original.jpg, the saved file will be crop(1).jpg

[Notice] If Photo size is of less than 540x720 or 720x540 pixels, it will display the following warning message.



Fig.6

5. The Photo Frame Area Pane






Fig.7

- ① **Photo Frame** : While Auto Run Program connects to 9 , Photo Frame will display all the supporting memory card format in 9 Photo Frame. You may click on the target storage devices, e.g. Photo Frame, SD/MMC, CF Card, MS, and XD.
- ② **Album** : When you select one of storage devices, this area will display all albums belonging to this device. Once you choose the album, all photos belonging to this album will be shown in (3).

[CAUTION] Please do not disconnect USB connection between PC and Photo Frame, while you use Auto Run Program to copy, move or delete photos in Photo Frame. It may cause the loss of data or photo if the user unplugs USB cable while Auto Run Program is still transmitting data.

- ③ **Photo Thumbnail View** : Display all photos in thumbnail view based on the album from Photo Frame (1) selected by the user.
- ④ **Photo Preview Area** : Display the user selected picture with detailed information, such as file name, file size and photo resolution.

- ⑤ **Slide Bar** : You may click  to move the Slide Bar to the left and increase the Photo Frame Area Pane. Vice versa, you may click  to increase the PC Area Pane.

To increase the browser view of [Photo Frame], please click , as shown in Fig.8.




Fig.8

6. The Command Keys Pane




Fig.9



Recycle Bin : You may click on Recycle Bin button to switch the target folder to the recycle bin folder. You may browse those removed photos and move them back to desired folders.



Setup Tool : You may setup application execution preferences and language preferences.

- **AutoRun:** You may select “Yes” radio button to execute the Philips Photo Frame Manager automatically, or select “No” to execute the Philips Photo Frame Manager manually. Please press “OK” to confirm the change you have just made as shown below in Fig.10.



Fig.10

- Language: You may select a desired language from the language pickup list. Please click "OK" to confirm the change you have just made.

[CAUTION] If your computer doesn't support the language you select, program may not display characters correctly. To solve this problem, please update language service packages from Microsoft Website.



Fig.11



Copy: You should select photos first, then click on the Copy button to copy the selected photos.



Cut: You should select photos first, then click on the Cut button to cut the selected photos.

[CAUTION] Photos can be cut from a memory card to a PC, but cannot be cut from PC to a storage device.



Fig.12



Paste: Right after you click on Copy or Cut button, Paste button will become available. You can select the target folder from the previous selected photos into the target folder (album).



Delete: You should select photos that you would like to remove, and click on the Delete button to remove those photos. The following confirmation window will pop up and ask you to double confirm. All deleted files will be moved into Recycle Bin. .




Fig.13



Delete Album: You should select albums you would want to remove, and click on the Delete button to remove those albums. The following confirmation window will pop up and ask you to double confirm. All deleted files will be moved into Recycle Bin.




Fig.14



Rename Album: You may click on Rename Album button to bring up Keyboard Input Window. You may key in the new name for selected album, and click on OK button to confirm this change.




Fig.15



New Album: To create a new album, you may select the target memory card first, and click on New Album button to bring up Keyboard Form window to input name for the album.




Fig.16




Close: You can click on Close button to minimize this application, which will be shown as a tray icon in taskbar. You can always bring back this application by right-clicking on this tray icon  and selecting "Show Photo Manager" option. Alternatively, you may terminate this application by selecting "Terminate Photo Manager".



Fig.17